

## AVAMIN DR

'Brissa' effect on dyed skins

### Typical Analysis

Appearance	: Yellowish Liquid
pH (10% sol.)	: 7-8
Active Substance	: 50-60 %
Ionic Character	: Amphoteric

### Properties

**Avamin DR** is a very special dischargen for all type dyed wool or hair. It gives Brissa effect at dyed wooled skins or furs

### Application

**Avamin DR** can be used directly or dilute or dilute with water and spray, brush or printing. After spray or brush skins wait 10 min. and thermo fix at 60-70 °C 20-30 min. steam. Under longer thermo fixation will be more white effect. Before thermo fixation wool or hair must be clean, with wool washing agents as **Unisol LC** or solvents